


Instruction Manual

Astro-AXS580DS



Congratulations!

We at Astro Drums would like to congratulate you on the purchase of the Astro AXE580DS Electronic drum kit. The included module, the AXE800DM, is designed to allow you to easily configure and tune your new Electronic Drum Kit the way you would your acoustic kit.

We strongly encourage you to read the entire manual before you proceed beyond the plug and play stages. There are helpful hints and tips that can improve the overall performance and sound of the AXE800DM. Good Luck and again thank you for choosing the AXE580DS.

Taking Care of Your Digital Drum Set

Your digital drum set will give you years of playing if you follow these basic steps below:

Location

Do not expose the unit to the following conditions to avoid deformation, discoloration, or more serious damage.

- Direct sunlight.
- High temperature (near a heat source, or in a car during the day time). Excessive humidity.
- Excessive dust.
- Strong vibration.

Power Supply

- Turn the power switch OFF when the AXE580DS not in use.
 - If an AC adaptor is used, it should be unplugged from the AC outlet if the instrument is not to be used for an extended period of time.
 - Unplug the AC adaptor during electric storms.
 - Avoid plugging the AC adaptor into the same AC outlet as an appliance with high power consumption, such as electric heaters or an oven.
- Also avoid using multi-plug adaptors since these can result in slower performance, operation errors, and possibly damage.

Turn Power OFF When Making Connections

- To avoid damaging to the AXE800DM and other devices that may be connected to it, turn OFF power switches of all related devices prior to connecting or disconnecting cables.

Handling and Transport

- Never apply excessive force to the controls, connectors or other parts of the AXE800DM.
- Always unplug cables by gripping the plug firmly, but not pulling on the cable.
- Disconnect all cables before moving the as AXE580DS.
- Physical shocks caused by dropping, bumping, or placing heavy objects on the AXE800DM can result in scratches and more serious damage.

Cleaning

- Clean the cabinet and panel with a dry soft cloth. A slightly damp cloth may be used to remove stubborn grime and dirt. Never use cleaners such as alcohol or thinner. Avoid placing vinyl objects on top of the unit (vinyl can stick to and discolor the surface).

Electrical Interference


- The AXE800DM contains digital circuitry and may cause interference if placed too close to radio or television receivers. If this occurs, move the AXE800DM further away from the affected equipment.

Contents

CONTROLS	4
- Front Panel	4
- Rear Panel	4
SETTING UP	5-7
- Connecting a MIDI Device	6
- Connecting a CD Player, etc.	6
- Connecting an Amplifier	6
- Using Headphones	7
- Connecting the Power Supply	7
START TO PLAY THE DRUM	8-9
1. Switch the power ON	8
2. Hit a pad	8
3. Play the DEMO song	8
4. Tempo	8
5. Change the Drum Kit	9
6. Click	9
PLAY SONG	10-11
1. Select a Song	10
2. Listen to the Song	10
3. Adjust the Song Volume	10
4. Change the Song's Tempo	10
5. Mute a Drum Voice	10
6. Play along with Click Voice	11
7. Change the Drum Kit	11
SONG	12-15
1. Repeat Playback	12
2. Merge Track	12
3. Play Back Track	13
4. Quantize Notes	13
5. Clear Track	14
6. Song Copy	14
7. Delete Song	15
VOICE	16-19
1. Select the Drum Voice	16
2. Change the Note Value	17
3. Change the Drum Volume	17
4. Change the Pad Function	18
5. Select Pad Song	18
6. Adjust the Reverb	18
7. Voice Copy	19
SONG RECORDING	20-21
1. Select the User Song	20
2. Set the Track	20
3. Get ready to record	20
4. Start Recording	21
5. Playback to the Song	21
UTILITY	22-26
1. Self Rejection, Rejection	22
2. Gain Minimum Velocity	22
3. Velocity Curve	23
4. Assign Order	23
5. Equalizer	23
6. Hi-Hat Offset	24
7. Trigger Bypass	24
8. Factory Set	24
9. Click Voice	25
10. Click Tune	25
11. Click Note Number	25
12. Use Tempo	26
13. System Real Time	26
14. Reverb Type, Reverb Time	26
15. Local Control	27
16. MIDI Merge	27
17. Program Change	27
18. System Exclusive Message	27
PAD ASSIGN	28
PRESET DRUM KIT LIST	29
DRUM VOICE LIST	30-31
SONG LIST	32
SPECIFICATIONS	33

Controls

Front Panel




- 1 POWER SWITCH
- 2 LCD DISPLAY
- 3 DATA DIAL
- 4 SONG
- 5 VOICE
- 6 UTILITY
- 7 KITS

- 8 PAD ASSIGN
- 9 DRUM OFF
- 10 TEMPO/TAP
- 11 START/STOP
- 12 MAIN VOLUME
- 13 AUX VOLUME
- 14 ACCOMP +/-

- 15 PAGE +/-
- 16 SAVE/ENTER/SELECT
- 17 CLICK
- 18 RECORD
- 19 DEMO
- 20 PHONES JACK

Rear Panel



- 1 MIDI IN/OUT JACK
- 2 TRIGGER INPUT


- 3 AUX IN JACK
- 4 AUX OUT JACK

- 5 MIDI IN/OUT JACK
- 2 TRIGGER INPUT

Setting Up

Caution!

To prevent electric shock and damage to the device, make sure the power is switched OFF on the drum brain and all related device before making any connection.




Setting Up

• Connecting a MIDI Device

Data in the drum brain can be accessed by any midi devise for storage, recording, and playback. Below you will find the instructions for the connection of your AXE800DM to an external midi device.


• Transmit MIDI Data

Use a MIDI cable to connect the MIDI OUT jack on the drum brain with the MIDI IN jack on the external MIDI device.




• Receive MIDI Data

Use a MIDI cable to connect the MIDI IN jack on the AXE800DM with the MIDI OUT jack on the external MIDI device.



• Connecting a CD Player, etc. (AUX IN jack)

The audio output from a CD player connected to the Aux IN jack on the rear panel can be mixed with the audio output of the AXE800DM. This function is convenient when you want to play along with a favorite song. The volume of the external signal is adjusted with the AUX VOLUME slider on the face of the AXE800DM.



• Connecting an Amplifier


An external amplifier can easily be connected the AXE800DM. Simply connect the AUX OUT jack on the back of the AXE800DM to a keyboard amplifier using a standard guitar cable.

The volume is adjusted with the MASTER VOLUME slider on the face of the AXE800DM.

Setting Up


● Using headphones

An optional set of stereo headphones can be connected to the PHONES jack located on the front of the unit.



● Connecting the Power Supply

Make sure the power switch is OFF and power adaptor to the DC IN jack on the rear



Before switching the power ON:

- To Protect the speakers, amplifier and the AXE800DM from damage, slide the master volume slider to the minimum volume level before switching the power ON.
- Make sure the power is switched OFF on all external devices connected to the AXE800DM. After the AXE800DM power is switched ON, switch the other device's power ON.

Start to play the drums

1. Switch the power ON


After confirming that each of the devices, pads, external devices, etc. are all properly connected, press the POWER ON/OFF button on the front panel to turn on the AXE800DM. The drum module is ready to operate when the display shown below, for selecting the drum kit and song appears (Song Mode).



SONG SEL
1 New World

2. Hit a pad

While hitting a pad, slide the MAIN VOLUME switch little by little upward until a comfortable volume level is reached.



3. Play the DEMO song

Press the [DEMO] button to start the demo song. To stop the demo song, press the [DEMO] button again or press the [START/STOP] button once.




DEMO
Now playing!

4. TEMPO

You can adjust the tempo range of the songs from 30 to 280.

Press the [TEMPO/TAP] button, you can tap the pad to get the current TEMPO. Tap 4 times and the beat is just as the interval of last two times you tap. After that the song will be playing at this tempo. You may also rotate the Data Dial to adjust the tempo. When the song is playing, the tapping method will not take effect.




SONG TEMPO
Tempo: 80

Start to play the drums

5 . Change the Drum Kit

Drum kit numbers 1-30 consist of 30 preset drum kits.

Press the [kits] button, the display below will be shown, with the kit # Flashing.




Drum Kits Number

Turn the Data

Dial to select the Drum Kit Number.

6 . Click

Press the [CLICK] button to start the metronome. To turn off the metronome, press the [CLICK] button again. Please read the Utility section in this manual for instructions on how to adjust the parameters for the metronome.



Play Song

1. Select a Song

Press the [SONG] button, the song indicator will begin flashing on the display:



Then turn the Data Dial to select the selected song.

2. Listen to the Song

Press the [START/STOP] button to playback the song
The song will stop when it reaches the end,
or stop the song during play back by pressing the [START/STOP] button.

3. Adjust the Song Volume

Press the [ACCOMP-] or [ACCCOMP+] to display the current accompany volume level.



Using the same display, press the [ACCOMP-] or [ACCCOMP+] button to adjust the accompany volume.

4. Changing the Song's Tempo

Press the [TEMPO/TAP] button to display the tempo setting,



Turn the Data Dial to set the tempo (30-280).
Press the [SONG] button to return the Song Mode display.

5. Mute a Drum Voice

Press the [DRUM OFF] button, a "D" sign will appear on the bottom right of the Song Mode display, and the main drum part song will be muted.



You can then play along with the song. Press the [DRUM OFF] button again and the drum part will restore.

Play Song

6 . Play along with the Click Voice


Press [CLICK] button to start the metronome. The click's LED will flash.



To turn off the metronome, press the [CLICK] Button again.

7. Change the Drum Kit

Press the [KIT] button to select a different drum kit with the selected song.



Then turn the Data Dial to select the drum kit number (1-30).
(When a song is started, the kit number will shift to its default automatically.
If you want to use another kit, you can only change it when the song is playing.)

Song

1. Repeat Playback

1.1 In the song Mode, press the [PAGE+] button to reach the song repeat display:



SONG
Kit:2 Rep:off

1.2 Press the [SELECT] button to move the flashing cursor to the Repeat on/off position, and then turn the Data Dial to set repeat play.

2. Merge Track


Before you can use the merge operation, it is necessary to select the User Song (Number 51-54). This function merges the data in track 1 and track 2 of the user song to track 1.

2.1 In the Song Mode, press the [PAGE+] button to select the Merge Track Model setting display shown below:



USER SONG TR:1
Mer9 Track #

2.2 Press the [SAVE/ENTER] button and the confirmation display shown below will appear:



Are you sure?

2.3 Press the [SAVE/ENTER] button again to confirm.

“Complete!” will appear, then the display will return to Song mode.

(Press the [SONG] button to cancel the merge track operation, and return to Song Mode display. *If a preset SONG (No. 1-50) is already selected, the following display will appear and the User Song Mode cannot be entered.



CAN'T EDIT
PRESET SONG

Press the [SONG] button to return to Song Mode display.

Song

1. Play Back Track

In the Song Mode, press the [PAGE+] button to select the Playback Track setting display shown below:



```
USER SONG TR:1
Play Back: 1
```

- “TR:—” The tracks in the user song are empty.
- “TR: 1” Track 1 already has recorded data.
- “TR: 2” Track 2 already has recorded data.
- “TR: 1&2” Both track (1 & 2) already has recorded data.


Turn the Data Dial to select tracks to be playback.

- * If the User Song contains 2 tracks, you can only
Playback track 1 (*PLAY BACK: 1*)
Or track 2 (*PLAY BACK: 2*),
Or playback two tracks together (*PLAY BACK: 1 & 2*)

When in playback mode, the kit playing will be the recording kit.

4. Quantize Notes

4.1 In the Song Mode, press the [PAGE+] button to select the quantize setting display shown below:



```
USER SONG TR:1
Quan: 1/8 Tr:1 ←
```

Quantize Note Value Track Number

Turn the Data Dial to select the quantize value:

- 1/4*: quarter note
- 1/8*: eighth note
- 1/12*: eighth note triplet
- 1/16*: sixteenth note
- 1/24*: sixteenth note triplet

4.2 Press the [SELECT] button, When the track indicator flashes on display, turn the Data Dial to assigns the track (1 or 2) to be quantized.

4.3 Press the [SAVE/ENTER] button, and the confirmation display shown below will appear:



```
Are you sure?
```

4.4 Press the [SAVE/ENTER] button again to confirm.

“COMPLETE!” will appear, then the display will return to Song mode.

(Press the [SONG] button to cancel the quantize operation, and return to the Song Mode display.)

The quantize operation is not available when a song is playing, and the display will return to Song Mode display.

Song

5. Clear Track

This function clears all data in the assigned track (1 or 2) in the user song.

5.1 In the Song Mode, press the [PAGE+] button to select the Clear Track setting display shown below:

A rectangular LCD display showing two lines of text in a pixelated font. The first line reads "USER SONG TR:1" and the second line reads "Clean Track: 1 #".

Turn the Data Dial to assign the track you want to clear (track 1 or track 2).

5.2 Press the [SAVE/ENTER] button, the confirmation shown below

A rectangular LCD display showing a single line of text in a pixelated font: "Are you sure?".

5.3 Press the [SAVE/ENTER] button again to confirm.

"COMPLETE!" will appear, then the display will return to Song mode.

(Press the [SONG] button to cancel the Clear Track operation, and return to the Song Mode display.)

The Clear Track operation is not available when a song is playing, and the display will return to Song Mode display

6. Song Copy

This function copies the preset song to the user song

6.1 In the song mode, press the [PAGE+] button to select the Song copy setting display shown below:

A rectangular LCD display showing two lines of text in a pixelated font. The first line reads "USER SONG TR:1" and the second line reads "Copy From: 1".

Song Number

Turn the Data Dial to assign the preset song (No. 1-50).

6.2 Press the [SAVE/ENTER] button, and the confirmation display shown below will appear:

A rectangular LCD display showing a single line of text in a pixelated font: "Are you sure?".

6.3 Press the [SAVE/ENTER] button again to confirm.

"COMPLETE!" will appear, then the display will return to song mode.

The data in track 2 will be deleted thoroughly this after operation.

(Press the [SONG] button to cancel the song copy operation, and return to the song mode display.)

The song copy operation is not available when a song is playing, and the display will return to song mode.

Song

7. Delete Song

This function clears all data in the assigned track 1 or track 2 in the user song.

7.1 In the Song Mode, press the [PAGE+] button to select the Delete Song setting display shown below:



USER SONG TR:1
Delete Song #

7.2 Press the [SAVE/ENTER] button, and the confirmation display shown below will appear:



Are you sure?

7.3 Press the [SAVE/ENTER] button again to confirm.

"COMPLETE" will appear, then the display will return to Song Mode.

(Press the [SONG] button to cancel the Delete Song operation, and return to the Song Mode.)


The Delete Song operation is not available when a song is playing, and the display will return to Song mode.

Voice

1. Selecting the Drum Voice

1.1 Selecting the Drum voice category


Press the [VOICE] button to enter the Voice Mode display, the voice category indicator flashes on the display:



Turn the Data Dial to select the drum voice category.

1.2 Selecting the Drum Voice


Press the [SELECT] button, the voice number indicator will flash on the display:



Turn Data Dial to select the drum voice category.

1.3 Selecting a Drum for the Input Source

Press the [SELECT] button, the voice input source indicator will flash on the display:



Turn the Data Dial to select the input source that is connected to the trigger input jack selected.


The value "V=1" indicates that the layer number is 1. two voices can be delivered with one input source.

Voice

2. Changing the Note value

Changing the note value of each pad's MIDI out.

In the Voice Mode, press the [PAGE+] button to select the Note value setting display shown below:



Turn the Data Dial to define the note value.


Use the [SELECT] button to select the input source.

3. Changing the Drum Volume

3.1 Changing the PAD Volume

Changing the volume of the drum voice when the pad is hit.

In the Voice Mode, press the [PAGE+] button to select the volume setting display shown display:




Turn the Data Dial to set the volume level (0-127).

3.2 Changing the PAN Position

The pan setting can move the position of the currently selected drum voice within the stereo field.

Use the same display; press the [SELECT] button, the Pan indicator flashes on the display:



Turn the Data Dial to set the Pan/Position (1-63 represents Left, 64 represents Center, 65-127 represents Right)

Voice

4. Changing the Pad Function

In the Voice Mode, press the [PAGE+] button to select the function setting display shown below:

```
PAD IN=Pad 2
Func: Normal
```

Turn the Data Dial to assign other functions to the trigger attached to the input source.

“NORMAL”: The drum pad is used for normal pad operations.

“CLICK ON OFF”: Turns the click sound on/off

“START/STOP”: Assign the playback function to the current Song.

“PAD SONG”: Assign the playback of the pad song to the pad

Caution: If there is more than one pad assigned to playback a pad song, The pad song playing will stop immediately and the other pad song will start when another pad is struck.

Also when a pad song is playing, you may only change the parameters on current page. If you can change pages, the song will stop immediately.

5. Selecting the Pad Song

The pad song function is assigned to the pad by selecting the song number to be played back when the current pad is struck. In the Voice Mode, press the [PAGE +] button to select the song setting display shown below.

```
PAD IN=Pad 2
Song: 1 Rep: off
```

Turn the Data Dial to select the song number (1-54) that will be assigned as the pad song.

Using the same display, press the [SELECT] button, the repeat indicator will flash in the display, turn the Data Dial to select repeat playback of the song or normal play.

6. Adjusting the Reverb

In the Voice Mode, press the [PAGE+] button to select the reverb settings shown below:

```
PAD IN=Pad 2
Reverb Send: 70
```

Turn the Data Dial to set the reverb value (0-127).

When the reverb value is set to 0, There will no longer be any reverb. As you increase the reverb value, the amount of reverb applied to the voice will also increase.

Voice

7. Voice Copy

This function will copy the input source data to another pad.

In the Voice Mode, press the [PAGE+] button to select the copy setting display shown below:



```
PAD IN=Pad 2
Copy to: Pad 2 *
```

Turn the Data Dial to set the destination pad (Pad 1-7/Pedal/Open/Closed).

- 7.1 When the destination pad is selected, press the [SAVE/ENTER] button, and the confirmation display shown below will appear:



```
Are you sure?
```

- 7.2 Press the [SAVE/ENTER] button again to confirm.
(Press the [VOICE] button to cancel the copy operation, and return to the Voice Mode display.)

Song Recording

Song recording lets you record data, produced as the drum kit is played to the sequencer in real-time (one track at a time). All MIDI channels are recorded simultaneously.

1. Select the User Song

Press the [RECORD] button to enter the record mode:

```
RECORD   TR:  --
User Song:51
```

Turn Data Dial to set the User Song number (no. 51-54) that you want to record to.

*Only user songs no.51-54 can be used for recording.

*User songs that have been previously recorded to, may not be selected for recording.

"TR—" The Tracks in the user song is empty.

"TR: 1" Track 1 already has recorded data.

"TR: 2" Track 2 already has recorded data.

"TR: 1 & 2" Both track (1&2) already have recorded data.

2. Set the Track

Press the [PAGE+] button, the display shown below:

```
RECORD   TR:  --
Track: 1
```

Then turn the Data Dial to select a track 1 or 2 for recording.

*User Songs contain 2 tracks that can be recorded to.

3. Getting ready to record

Press the [PAGE+] button to get ready to record:

```
RECORD
Get ready!
```

Song Recording

4. Start Recording

Press the [START/STOP] button to start recording:



```
Now recording!
```

*When a track has pre-recorded data and the [START/STOP] button is pressed, the error message shown below will appear:



```
ERROR  
Track not empty!
```


5. Playback to the Song

After you have recorded a performance, you can press the [START/STOP] button to playback the recorded performance. Playback stops when the [START/STOP] button is pressed again or the song will stop when it reaches the end.

Utility

1. Self Rejection, Rejection

This function is used to prevent double triggering and cross talk (mixed input signals between the jacks) between each of the pads. Press the [UTILITY] button to enter the Utility Mode, the LCD will display:



1.1 Self Rejection (SelfRej)

Prevents double triggering from occurring between the pad assigned to the UT PAD IN. After an event is detected, further events will be automatically muted for a certain length of time. Larger values will have longer times. Turn the Data Dial to select the pad (0-9).

1.2 Rejection (Rej)

Prevents cross talk from occurring between the pads assigned to the UT PAD IN. Events triggered by other pads that are of a lower than the input value set here, will no be delivered for a set length of time. Press the [SELECT] button, then turn the Data Dial to select the pad (0-9).

1.3 UT PAD IN

Turn the Data Dial to select the drum pad number.

2. Gain, Minimum Velocity

This function sets the input sensitivity (Gain) and velocity range (Minimum Velocity) for each pad. In the Utility Mode, press the [PAGE+] button to select the gain/velocity setting display shown below:



2.1 Gain

Adjusts the input gain level for the pad assigned. Entering a larger value here allows smaller input levels to sound the voice. Turn the Data Dial to select the gain level (0-99)

2.2 Minimum Velocity (Mvel)

Sets the MIDI Velocity that is transmitted when the pad is hit the weakest. Large values will be produced even if the pad is hit softly. However, this will result in a narrower volume range, making it difficult to adequately produce wider dynamic levels. Press the [SELECT] button, then turn the Data Dial to select the velocity level (1-27).

2.3 UT PAD IN


Turn the Data Dial to select the drum pad number.

Utility

3. Velocity Curve

This function sets the MIDI Velocity.

In the Utility Mode, press the [PAGE+] button to select the velocity curve setting display shown below:



3.1 Velocity Curve (Velcurve)

The MIDI velocity curve adjusts the over all sensitivity curve for the pad selected.

Turn the Data Dial to select the curve (Normal, Loud 1, Loud 2, Hard 1, Hard 2).


3.2 UT PAD IN

Turn the Data Dial to select the drum pad number.

4. Assign Order

This sets the pad function that allows the currently selected drum kit number to be increased or decreased by hitting the specified pad.

In the Utility Mode, press the [PAGE+] button to select the assigned order setting display shown below:



4.1 Assign Order

Turn the Data Dial to assign increment (Inc) or Decrement (Dec).

4.2 UT PAD IN

Turn the Data Dial to select the drum pad number.

5. Equalizer

In the Utility Mode, press the [PAGE+] button to select the equalizer setting display shown below:



5.1 Low Gain (EQ Lo)

Turn the Data Dial to adjust the low gain level range from (0-12dB).

5.2 High Gain (EQ Hi)

Press the [SELECT] button, then turn the Data Dial to adjust the high gain level rang from (0-12dB).

Utility

6. Hi-Hat Offset

This sets the value of the data sent by the foot controller connected to the HI-HAT CONTROL jack on the rear panel. In the Utility Mode, press the [PAGE+] button to select the Hi-Hat offset setting display shown below:



UT SYSTEM
HH Offset:-31

Turn the Data Dial to set the value.

*When a low data value is received from a foot controller, the voice will sound sooner. So, slightly pressing the foot controller will result in the voice sounding. In the case of the hi-hat controller, adjustment of the controller's "closed" point is possible.

7. Trigger Bypass

This function prohibits reception of pad signals from pads (the Hi-Hat controller too) connected to the drum brain. You will not be able to produce voices or transmit MIDI data. The sequencer and tone generator will function normally. In the Utility Mode, press the [PAGE+] button to select the trigger bypass setting display shown below:



UT SYSTEM
TrigBypass:off

Turn the Data Dial to set the value.

On: Bypasses the trigger (does not receive).

Off: The trigger input functions normally (receives trigger).

8. Factory Set


This function resets all of the all internal settings

8.1 In the Utility Mode, press the [PAGE+] button to select the factory setting display shown below:



UT SYSTEM
Factory Set #

8.2 Press the [SAVE/ENTER] button, the confirmation shown below:



Are you sure?

8.3 Press the [SAVE/ENTER] button again to confirm.

"COMPLETE" will appear, then the display will return to Song mode.

(Press the [Utility] button to cancel the rest operation, and return to the Utility Mode display.)

Utility

9. Click Voice

This function sets the drum voice used for the click sound. In the Utility Mode, press the [PAGE+] button to select the click voice setting display shown below:

```
UT SEQ CLICK
P/ 29 MtBe1
```

9.1 Voice Category

Sets the voice to be used for the Click Voice.
Turn the Data Dial to select category.

9.2 Voice Number, Voice Name

Selects the voice that will be assigned. If the parameter is set to 0, "No Assign" will appear on the display and sound will not be produced. Press the [SELECT] button, then turn the Data Dial to select the voice.

10. Click Tune

This function sets the pitch of the click voice.

In the Utility Mode, press the [PAGE+] button to select the click tune setting display shown below:

```
UT SEQ CLICK
Tune C: 0 F: 0
```

10.1 Tune Coarse (Tune C)

The Click Voice will be tuned in increments for a half-step
Turn the Data Dial to set the tune coarse value (-24 to 0 to +24).

10.2 Tune Fine (Tune F)

The Click Voice will be tuned in increments of about 1.17 cents.
Press the [SELECT] button, then turn the Data Dial to set the tune fine value (-64 to 0 to +63).

11. Click Note Number

Sets the MIDI Note Number for the Click Voice.

In the Utility Mode, press the [PAGE+] button to select the click note setting display shown below:

```
UT SEQ CLICK
Note: 21
```

Turn the Data Dial to set the click note (0-127).

Utility

12. Use Tempo

This function determines when a song will return to its default tempo or remain at the currently set tempo when the song is changed. In the Utility Mode, press the [PAGE+] button to select the use tempo setting display shown below:

```
UT SEQ SETUP
Use Tempo: Song
```

Turn the Data Dial to set the value.

“*SONG*”: Changes the tempo of the song to its default tempo, when the song is changed.

“*GLOBAL*”: The tempo remains unchanged at the currently set tempo, when the song is changed.

13. System Real Time

This enables or disables the TY 602's ability to transmit or receive system real time message (start/continue/stop). In the Utility Mode, press the [PAGE+] button to select the system real time setting display shown below:

```
UT SEQ SETUP
SYS Realtime: off
```

Turn the Data Dial to set the value.

“*ON*”: Transmits and receives the system real time messages.

“*OFF*”: Does not transmit and receives system real time messages.

14. Reverb Type, Reverb Time

This function sets the reverb effect on the drum.

In the Utility Mode, press the [PAGE +] button to select reverb type and time setting display shown below:

```
UT REVERB SETUP
Type: Hall2 T: 32
```

14.1 Reverb

Turn the Data Dial to set the reverb type:

ROOM1 ROOM2 ROOM3 HALL1 HALL2 PLATE DELAY

Type (Type)

14.2 Reverb Time (T)

Press the [Select] button, then turn the Data Dial to set the reverb time (0-127).

Utility

15. Local control

In the Utility Mode, press the [PAGE+] button to select the local control setting display shown below:



UT MIDI SETUP
Local: on

Turn the Data Dial to set the Local Control (on or off).

Off: MIDI signals triggered by the connected pads will be disconnected from the AXE800DM's tone generator. This will cause no sound to be produced by the AXE800DM's tone generator, when a pad is played. The AXE800DM will continue to transmit MIDI signals from the MIDI out only.

On: Normal operation. MIDI signals will be transmitted to the AXE800DM's tone generator as well as the MIDI OUT jacks.

16. MIDI Merge

In the Utility Mode, press the [PAGE+] button to select the MIDI merge setting display shown below:



UTI MIDI SETUP
Merge output: off

Turn the Data Dial to set the Local Control (on or off).

Off: MIDI signals triggered by the connected pads will be disconnected from the AXE800DM's tone generator. This will cause no sound produced by the AXE800DM's tone generator. The AXE800DM's will continue to send MIDI signals from the MIDI out only.

On: Normal operation. MIDI signals will be transmitted to the AXE800DM's tone generator as well as the MIDI OUT jacks.

17. Program Change

In the Utility Mode, press the [PAGE+] button to select the program change setting display shown below:



UT MIDI RECEIVE
PC: on

Turn the Data Dial to set the receive program (on or off).

It is necessary to set the receive parameter to ON in the display, in order to change the drum kits used in a song or on an external MIDI device

OFF: Does not receive

ON: Receives

18. System Exclusive Message

In the Utility Mode, press the [PAGE+] button to select the system exclusive setting display shown below:



UT MIDI RECEIVE
SysEx: off

Turn the Data Dial to set the System Exclusive Message (on or off).

This enables or disables the drum to receive system exclusive messages from all MIDI channels.

OFF: Does not receive system exclusive messages.

ON: Receives system exclusive messages.

Pad Assign

This function allows you to quickly set up the sounds you will be using on your AXE580DS. By selecting the drum pad in the PAD ASSIGN, you can tap the pads to toggle through the drum voices in the selected category.

1. Select the Voice Category

Press the [PAD ASSIGN] button, the LCD display:



PAD ASSIGN: Pad 2
S/ 15 Wood Sn

Turn the Data Dial to set the voice category.

2. Select the Voice Number


Press the [SELECT] button, then turn the Data Dial to select the voice number.

You can assign the voice by turning the Data Dial or by tapping the pad. This means, when you hit the pad the voice will change. Continue to hit the pad until you reach the voice you desired.

3. Save the user Drum Kit

3.1 Press the [SAVE/ENTER] button, and the LCD display shown below will appear:

:



Save to kit: 21
Are you sure?

3.2 Turn the Data Dial to set the drum kit number (21-30) you will be saving to.

3.3 Press the [SAVE/ENTER] button again to save it, then the display will return to previous display. (Press the [PAD ASSIGN] button to cancel the save operation, and return to the Pad Assign Mode display).

Preset Drum Kit List

Kit 1,21 1 kick 2 snare 3 tom1 4 tom2 5 tom3 6 ride 7 crash Open Close Pedal	Standard1 K/3 BD DRY1 S/15 Wood Sn T/2 DRY GM5 T/4 DRY GM3 T/6 GRY GM1 C/11 RideLite C/1 CrashB H/20 Hhopen#1 H/1 H Cls01 H/22 H PdILit	Kit 2 1 kick 2 snare 3 tom1 4 tom2 5 tom3 6 ride 7 crash Open Close Pedal	Standard2 K/3 BD DRY1 S/65 S SStck3 T/2 DRY GM5 T/4 DRY GM3 T/6 GRY GM1 C/11 RideLite C/1 CrashB H/20 Hhopen#1 t/1 Ana 1Hi H/22 H PdILit	Kit 3,22 1 kick 2 snare 3 tom1 4 tom2 5 tom3 6 ride 7 crash Open Close Pedal	Dance 1 k/4 BDDance1 S/6 AnalogH1 t/6 AnlgTom5 t/8 AnlgTom3 t/10 AnlgTom1 C/11 RideLite C/2 BriteCrs H/24 H OpnAMu H/4 H ClsA2 H/3 H ClsA1	Kit 4,23 1 kick 2 snare 3 tom1 4 tom2 5 tom3 6 ride 7 crash Open Close Pedal	Jazz Latin K/8 2HeadHi S/65 S SStck3 T/8 Jazz Mid T/10 Jazz Flr T/41 Room2 Lo C/11 RideLite C/1 CrashB H/20 Hhopen#1 H/1 H Cls01 H/22 H PdILit
Kit 5,24 1 kick 2 snare 3 tom1 4 tom2 5 tom3 6 ride 7 crash Open Close Pedal	Room 1 K/11 BD Room2 S/3 MapleA50 T/21 Room 4 T/22 Room 3 T/24 Room 1 C/11 RideLite C/2 BriteCrs H/20 Hhopen#1 H/1 H Cls01 H/22 H PdILit	Kit 6 1 kick 2 snare 3 tom1 4 tom2 5 tom3 6 ride 7 crash Open Close Pedal	Electric K/18 BD GateM S/63 RockL t/25 E Tom4 t/26 E Tom3 t/28 E Tom1 C/11 RideLite C/2 BriteCrs H/20 Hhopen#1 H/1 H Cls01 H/22 H PdILit	Kit 7 1 kick 2 snare 3 tom1 4 tom2 5 tom3 6 ride 7 crash Open Close Pedal	Brush K/12 BD Room5 S/53 BrshTap2 T/11 BrshJzHi T/13 BrshJzLo T/14 BrshJzF1 C/13 RideRoc2 C/1 CrashB H/20 Hhopen#1 H/1 H Cls01 H/22 H PdILit	Kit 8 1 kick 2 snare 3 tom1 4 tom2 5 tom3 6 ride 7 crash Open Close Pedal	Room_stick K/11 BD Room2 S/65 S SStck3 T/21 Room 4 T/22 Room 3 T/24 Room 1 C/11 RideLite C/2 BriteCrs H/20 Hhopen#1 H/1 H Cls01 H/22 H PdILit
Kit 9 1 kick 2 snare 3 tom1 4 tom2 5 tom3 6 ride 7 crash Open Close Pedal	Latin 1 K/3 BD DRY1 S/15 Wood Sn T/2 DRY GM5 T/4 DRY GM3 T/5 GRY GM2 C/11 RideLite C/2 BriteCrs P/18 CowB1 P/18 CowB1 H/22 H PdILit	Kit 10 1 kick 2 snare 3 tom1 4 tom2 5 tom3 6 ride 7 crash Open Close Pedal	Latin 2 K/3 BD DRY1 S/65 S SStck3 T/2 DRY GM5 T/4 DRY GM3 T/5 GRY GM2 C/11 RideLite C/2 BriteCrs P/18 CowB1 P/18 CowB1 H/22 H PdILit	Kit 11 1 kick 2 snare 3 tom1 4 tom2 5 tom3 6 ride 7 crash Open Close Pedal	Jazz K/8 HeadHi S/3 MapleA50 T/8 Jazz Mid T/10 Jazz Flr T/41 Room2 Lo C/11 RideLite C/1 CrashB H/20 Hhopen#1 H/1 H Cls01 H/22 H PdILit	Kit 12,25 1 kick 2 snare 3 tom1 4 tom2 5 tom3 6 ride 7 crash Open Close Pedal	Brush 2 K/12 BD Room5 S/50 BrshSlp T/12 BrshJzMd T/14 BrshJzF1 T/18 BrshRkF1 C/13 RideRoc2 C/22 C Splsh1 s/46 BrshAtak s/46 BrshAtak H/22 H PdILit
Kit 13 1 kick 2 snare 3 tom1 4 tom2 5 tom3 6 ride 7 crash Open Close Pedal	Dance-stick K/4 BDDance1 s/48 BrshHit2 t/6 AnlgTom5 t/8 AnlgTom3 t/10 AnlgTom1 C/11 RideLite C/2 BriteCrs H/24 H OpnAMu H/4 H ClsA2 H/3 H ClsA1	Kit 14,26 1 kick 2 snare 3 tom1 4 tom2 5 tom3 6 ride 7 crash Open Close Pedal	Orchestra 1K/25 GrnCassa S/11 ToshSn T/42 Room2Flr T/10 Jazz Flr T/41 Room2 Lo C/25 Hcym1 C/26 HcymOpnL H/20 Hhopen#1 H/1 H Cls01 H/22 H PdILit	Kit 15,27 1 kick 2 snare 3 tom1 4 tom2 5 tom3 6 ride 7 crash Open Close Pedal	Drum&bass k/4 BDDance1 s/30 AnVelRim s/27 AnaShh s/11 AnHitRim k/15 BDRevers C/14 RidesizC C/7 PaperThn H/4 H ClsA2 H/3 H CIA1 H/24 H OpnAMu	Kit 16 1 kick 2 snare 3 tom1 4 tom2 5 tom3 6 ride 7 crash Open Close Pedal	House k/4 BDDance1 s/18 Dance06 s/7 AnalogL1 s/19 Elektrik P/43 Tamba C/8 ReverseC C/6 FastCras H/19 HHRoKopn H/20 Hhopen#1 H/21 H PdI13
Kit 17,28 1 kick 2 snare 3 tom1 4 tom2 5 tom3 6 ride 7 crash Open Close Pedal	R&B K/4 BDDance1 s/17 Dance05 s/18 Dance06 s/2 AnaDark P/43 Tamba C/13 RideRoc2 C/3 C Crash H/24 H OpnAMu H/16 H OpnLK H/15 H OpnL3	Kit 18,29 1 kick 2 snare 3 tom1 4 tom2 5 tom3 6 ride 7 crash Open Close Pedal	Jungle k/1 AnaQuick s/6 AnalogH1 S/56 RIMrock t/12 TEKK 1M t/6 AnlgTom5 C/11 RideLite C/2 BriteCrs H/24 H OpnAMu H/4 H ClsA2 H/3 H ClsA1	Kit 19,30 1 kick 2 snare 3 tom1 4 tom2 5 tom3 6 ride 7 crash Open Close Pedal	CHINA LUOGU K/26 DAGU1 P/55 GUBAN2 S/72 PAIGU 2 S/71 PAIGU 1 C/35 DALUO2 C/39 DAPO2 P/64 PENGLIN1 C/41 XIAOPO C/42 XIAOPOM C/41 XIAOPO	Kit 20 1 kick 2 snare 3 tom1 4 tom2 5 tom3 6 ride 7 crash Open Close Pedal	Oriental 1 K/26 DAGU1 S/72 PAIGU 2 C/33 DALUO1 C/41 XIAOPO C/35 DALUO2 C/37 DAPO1 C/39 DAPO2 C/41 XIAOPO C/42 XIAOPOM C/41 XIAOPO

Drum Voice List

Voice Category

K: AcousticKick
 k: Electric Kick
 S: Acoustic Snare
 s: Electric Snare
 T: Acoustic Tom
 t: Electric Tom
 C: Cymbal
 H: Hi-Hat
 P: Percussion

K: Acoustic Kick

1 2HedMed2
 2 Basic
 3 BD DRY 1
 4 BD DRY 4
 5 SoTight
 6 BDaftty1
 7 BDaftty2
 8 2HeadHi
 9 BD GMJ
 10 BD GML
 11 BD ROOM2
 12 BD ROOM5
 13 BD Soft
 14 BDersko1
 15 BD ROOM3
 16 BD GATE1
 17 BD GATE2
 18 BD GateM
 19 BD Meta1
 20 BD Rock1
 21 BD Rock2
 22 Bdevolvr
 23 Bdpalmer
 24 GrCMute
 25 GrnCassa
 26 DAGU1
 27 DAGU2

k: Electric Kick

1 AnaQuick
 2 BD ELEC2
 3 BD Rave8
 4 BDDance1
 5 BDDance2
 6 BDDance3
 7 BDDance4
 8 BDdance5
 9 BDlong1
 10 BDRave11
 11 Sub1
 12 Sub2
 13 Sub3
 14 BDNIN1
 15 BDRevers
 16 Walkik
 17 fefifofm

S: Acoustic Snare

1 Loosy
 2 Baryrim
 3 MapleA50
 4 MickMHS
 5 MapleV65
 6 Blu90Rim
 7 Blue90
 8 Hip Hop
 9 OldCan
 10 LiteSnr1
 11 Tosh Sn
 12 MapleRim
 13 BigWdRim
 14 BigWood
 15 Wood Sn
 16 Wood65
 17 ToshL fi
 18 Looz Pic
 19 PhlyRim
 20 RIMhipop
 21 SnareH2
 22 MickCJ8S
 23 Maple12
 24 12Soprno
 25 Picket
 26 Slappy
 27 BeautyRim
 28 Beauty
 29 BrassRim
 30 BuzRgRim
 31 Buzzring
 32 Jelyrim
 33 RIMnatri
 34 RIMouch
 35 RoldGold
 36 Steel
 37 VtgBras1
 38 VtgBras2
 39 MickDarS
 40 Brassy
 41 Fat looz
 42 Rock
 43 PicloRim
 44 Metalpic
 45 ClubOK
 46 ClubORri
 47 Piclodry
 48 Fusion
 49 TrashRIM
 50 Ambient1
 51 Ambt1rim
 52 Powerpic
 53 Pwrprcim
 54 Room
 55 Amb 03
 56 RIMrock
 57 RIMwatts
 58 Fatbrass
 59 Fatbrim

60 Brass55
 61 Gate
 62 RockH
 63 RockL
 64 RockM
 65 S SStck3
 66 S STK_HT
 67 Timbrim
 68 TambSnre
 69 SnRoll1*
 70 SnRoll2*
 71 PAIGU 1
 72 PAIGU 2
 73 PAIGU 3

s: Electric Snare

1 AnaDaRim
 2 AnaDark
 3 AnaHit
 4 Analog H
 5 Analog L
 6 AnalogH1
 7 AnalogL1
 8 AnaTite
 9 AnaWide
 10 AnaWiRim
 11 AnHitRim
 12 AnSStick
 13 Dance
 14 Dance01
 15 Dance02
 16 Dance03
 17 Dance05
 18 Dance06
 19 Elektrik
 20 SAmbie4
 21 SAna1
 22 CapGun
 23 CapRim
 24 Dryroom
 25 HiFive
 26 AnaBzRim
 27 AnaShh
 28 AnaShRim
 29 AnaSlegh
 30 AnVelRim
 31 ASOBI
 32 Blaaaghf
 33 Dry Guy
 34 Elem3
 35 FantaRim
 36 FX
 37 JelyRoll
 38 RIMshort
 39 RO_S
 40 RockRim
 41 RollEm2
 42 RollEm3
 43 RollRim2
 44 RollRim3

45 Sheetmtl
 46 BrshAtak
 47 BrshHit1
 48 BrshHit2
 49 BrshOp
 50 BrshSlp
 51 BrshSlpL
 52 BrshSwep
 53 BrshTap2
 54 BrshTap3
 55 BrshTp
 56 BrSwH*
 57 BrSwL*
 58 BrSwTime
 59 BrSwTRim

T: Acoustic Tom

1 DRY GM6
 2 DRY GM5
 3 DRY GM4
 4 DRY GM3
 5 DRY GM2
 6 DRY GM1
 7 Jazz Hi
 8 Jazz Mid
 9 JazzLo
 10 Jazz Flr
 11 BrshJzHi
 12 BrshJzMd
 13 BrshJzLo
 14 BrshJzF1
 15 BrshRkHi
 16 BrshRkMd
 17 BrshRkLo
 18 BrshRkFI
 19 Room 6
 20 Room 5
 21 Room 4
 22 Room 3
 23 Room 2
 24 Room 1
 25 Rock 6
 26 Rock 5
 27 Rock 4
 28 Rock 3
 29 Rock 2
 30 Rock 1
 31 ACTomH
 32 ACTomM
 33 ACTomL
 34 ACTomF
 35 Room1 Hi
 36 Room1Mid
 37 Room1 Lo
 38 Room1Flr
 39 Room2 Hi
 40 Room2Mid
 41 Room 2Lo
 42 Room2Flr

t: Electric Tom

1 Ana 1Hi
 2 Ana 1Mid
 3 Ana 1Lo
 4 Ana 1Flr
 5 AnlgTom6
 6 AnlgTom5
 7 AnlgTom4
 8 AnlgTom3
 9 AnlgTom2
 10 AnlgTom1
 11 TEKK 1H
 12 TEKK 1M
 13 TEKK 1L
 14 TEKK 1F
 15 TEKK 3H
 16 TEKK 3M
 17 TEKK 3L
 18 TEKK 3F
 19 AnaIndsH
 20 AnaIndsM
 21 AnaIndsL
 22 AnaIndsF
 23 E Tom6
 24 E Tom5
 25 E Tom4
 26 E Tom3
 27 E Tom2
 28 E Tom1
 29 HybridH
 30 HybridM
 31 HybridL
 32 HybridF

Drum Voice List

C: Cymbal

- | | | | | | |
|----|----------|----|-----------|----|----------|
| 1 | CrashB | 9 | HHRocKcls | 42 | TalknDrV |
| 2 | BriteCrs | 10 | H Opn13 | 43 | TambA |
| 3 | C Crash | 11 | H OpnDW | 44 | TimbH |
| 4 | DeepDRK | 12 | H OpnDWX | 45 | TimbL |
| 5 | FasCrash | 13 | H OpnL1 | 46 | TimpH |
| 6 | FastCras | 14 | H OpnL2 | 47 | TimpL |
| 7 | PaperThn | 15 | H OpnL3 | 48 | Triang |
| 8 | ReverseC | 16 | H OpnLK | 49 | TriMut |
| 9 | SoftRoll | 17 | H OpnLX1 | 50 | VibrSlap |
| 10 | C CrshSi | 18 | H OpnNB | 51 | Whist |
| 11 | RideLite | 19 | HHRoKopn | 52 | XfadeTri |
| 12 | RideRoc1 | 20 | Hhopen#1 | 53 | BANGU |
| 13 | RideRoc2 | 21 | H PdI13 | 54 | GUBAN1 |
| 14 | RidesizC | 22 | H PdILit | 55 | GUBAN2 |
| 15 | RideXfd | 23 | H PdTit | 56 | LHBAN |
| 16 | Rocksizl | 24 | H OpnAMu | 57 | ZHUBAN |
| 17 | Sizzler | 25 | H OpnAn | 58 | NANBANG |
| 18 | SizzlRck | | | 59 | DAMUYU |
| 19 | RidB Lit | | | 60 | SMUYU-1 |
| 20 | China | | | 61 | SMUYU-2 |
| 21 | ChinaHi | | | 62 | SMUYU-3 |
| 22 | C Splsh1 | | | 63 | SMUYU-4 |
| 23 | C Splsh2 | | | 64 | PENGLIN1 |
| 24 | C FX01 | | | 65 | PENLIN1M |
| 25 | HCym1 | | | | |
| 26 | HcymOpnL | | | | |
| 27 | MANGLUO1 | | | | |
| 28 | MANGL1M | | | | |
| 29 | MANGLUO2 | | | | |
| 30 | MANGL2M | | | | |
| 31 | MANGLUO3 | | | | |
| 32 | MANGL3M | | | | |
| 33 | DALUO1 | | | | |
| 34 | DALUO1M | | | | |
| 35 | DALUO2 | | | | |
| 36 | DALUO2M | | | | |
| 37 | DAPO1 | | | | |
| 38 | DAPO1M | | | | |
| 39 | DAPO2 | | | | |
| 40 | DAPO2M | | | | |
| 41 | XIAOPO | | | | |
| 42 | XIAOPOM | | | | |
| 43 | XIAOLUO | | | | |
| 44 | XIAOLUOM | | | | |
| 45 | TENLUO1 | | | | |
| 46 | TENLUO1M | | | | |
| 47 | GOULUO | | | | |
| 48 | GOULUOM | | | | |

P: Percussion

- | | |
|----|----------|
| 1 | AgogoH1 |
| 2 | AgogoH2 |
| 3 | Bell Tre |
| 4 | Bongo Hi |
| 5 | Bongo Lo |
| 6 | Cabasa1 |
| 7 | Cabasa2 |
| 8 | Castanet |
| 9 | ClapA |
| 10 | Clvs |
| 11 | ClvsA |
| 12 | Conga8H |
| 13 | CongaM |
| 14 | CongaMv |
| 15 | CongaAn |
| 16 | CongaO |
| 17 | CongBe |
| 18 | CowB1 |
| 19 | CowBM |
| 20 | CuicaH |
| 21 | CuicaL |
| 22 | Fsnap2 |
| 23 | Guiro |
| 24 | GuiSht |
| 25 | HiQ |
| 26 | JingBell |
| 27 | Maracas1 |
| 28 | Maracas2 |
| 29 | MtBel |
| 30 | Mtron |
| 31 | Scrach |
| 32 | Shake 1 |
| 33 | Surdo |
| 34 | SurdoM |
| 35 | Tabla B |
| 36 | Tabla BL |
| 37 | Tabla BM |
| 38 | Tabla BV |
| 39 | TalkD |
| 40 | TalknDrD |
| 41 | TalknDrU |

H: Hi-Hat

- | | |
|---|----------|
| 1 | H Cls01 |
| 2 | H Cls13 |
| 3 | H ClsA1 |
| 4 | H ClsA2 |
| 5 | H QOpn13 |
| 6 | H TiCls1 |
| 7 | HHcl2Xfd |
| 8 | HHclsXfd |

Song List

- 1 NEW WORLD
- 2 HOT SAMBA
- 3 ORGAN FUNK
- 4 MAMBO
- 5 SPEED
- 6 HOLIDAY
- 7 HIP HOP
- 8 WALK
- 9 BRUSH JAZZ
- 10 TRANCE
- 11 HARD ROCK 1
- 12 HARD ROCK 2
- 13 SLOW ROCK
- 14 ROCK & POP 1
- 15 ROCK & POP 2
- 16 ROCK & POP 3
- 17 ROCK & POP 4
- 18 SALSA
- 19 BEGUIN
- 20 BOSSANOVA
- 21 REGGAE
- 22 FUNK 1
- 23 FUNK 2
- 24 FUNK 3
- 25 SHUFFLE
- 26 FUSION
- 27 BIG BAND
- 28 JAZZ
- 29 DISCO
- 30 HOUSE
- 31 JUNGLE
- 32 R & B 1
- 33 R & B 2
- 34 R & B 3
- 35 R & B 4
- 36 ROCK 'N' ROLL 1
- 37 ROCK 'N' ROLL 2
- 38 8BEAT 1
- 39 8BEAT 2
- 40 16 BEAT 1
- 41 BALLAD 1
- 42 BALLAD 2
- 43 BALLAD 3
- 44 BALLAD 4
- 45 BALLAD 5
- 46 BALLAD 6
- 47 WALTZ
- 48 MARCH
- 49 JING OPEROR
- 50 CHINESERYTH

Specifications

Drum Pad: 7 drum pads + 2 pedals

Voices: 389 voices

Drum kits: 20 preset , 10 user kits

Demo Song: 1 demo song

Song: 50 preset, 4 user songs

Controls: POWER SWITCH, SONG, VOICE, UTILITY, KITS, PAD ASSIGN, DRUM OFF, TEMPO/TAP, START/STOP, MASTER VOLUME, AUX VOLUME, ACCOMP VOLUME +/-, PAGE +/-, SAVE/ENTER, SELECT, CLICK, RECORD, DEMO, DATA DIAL

Display: LCD display

Connections: DC IN
Aux Out
Aux In
Hi-Hat control
Hi-Hat
Snare
Tom 1
Tom 2
Tom 3
Ride
Crash
Kick
MIDI IN/OUT

Power Supply: DC 9V